

Guidelines on choosing the size of a sling

All dimensions in inches

ABC Slings	Kids	Kids	Kids	Kids	XS	S	M	L	XL	2XL	3XL
<p>W1 W2 H</p>	2 - 4	4 - 6	6 - 10	10 - 14							
H		17 ⁷ / ₈ - 23 ⁵ / ₈	21 ⁵ / ₈ - 27 ¹ / ₄	26 ⁶ / ₈ - 31 ⁴ / ₈	29 ⁴ / ₈ - 32 ² / ₈	31 ⁴ / ₈ - 34 ² / ₈	33 ⁴ / ₈ - 36 ² / ₈	35 ³ / ₈ - 38 ² / ₈	37 ³ / ₈ - 40 ¹ / ₈	37 ³ / ₈ - 40 ¹ / ₈	37 ³ / ₈ - 40 ¹ / ₈
W1		9 ⁷ / ₈ - 11 ⁶ / ₈	11 - 13 ⁶ / ₈	13 - 15	13 - 14 ⁵ / ₈	14 ¹ / ₈ - 15 ⁶ / ₈	15 ³ / ₈ - 16 ⁷ / ₈	16 ⁴ / ₈ - 17 ⁶ / ₈	17 ⁶ / ₈ - 19 ² / ₈	18 ⁷ / ₈ - 20 ³ / ₄	20 ³ / ₄ - 22 ⁷ / ₈
W2 ^{x)}		21 ¹ / ₂ - 35	17 ⁷ / ₈ - 25	25 ³ / ₈ - 39 ¹ / ₄	30 ³ / ₈ - 41	29 ¹ / ₂ - 43 ¹ / ₄	31 ¹ / ₂ - 47 ¹ / ₄	35 ⁵ / ₈ - 51	39 ¹ / ₄ - 55	43 ¹ / ₄ - 59	up to 91
W2 ^{xx)}	18 - 21	19 ¹ / ₂ - 25 ³ / ₈	19 ⁷ / ₈ - 28	21 ⁷ / ₈ - 29 ¹ / ₄							

W2 = Chest measurements

x) Guideline for choosing Active slings

xx) Guideline for choosing Active Vest Kids